

NÁVOD NA MONTÁŽ POSTREKOVÁČOV - **IrriPlanner**

1. Tryska MP rotator, alebo spray
2. Postrekovač PRO-SPRAY
3. Kolená IT 20x1/2 voz"
4. Hadica LDPE 6 Bar 20mm
5. Zátka PP 25 mm
6. Hadica LDPE 6 bar 25 mm
7. Navrtávací pás 25x1/2"
8. T-kus PP 25mm

Hadice treba zakopat' Privod vody
do 20cm hĺbky.

